How to active Modbus driver?

Applies to:

Platform	*OS version*
PC	*Windows 98/NT/2000/XP/Vista*

At least one ICP DAS Modbus device needs to be connected when you install Modbus drivers, then the Modbus drivers can access other Modbus devices like PLC.

The following ICPDAS device can be connected to active all the Modbus driver.

M7000 serial modules
I-7188EX-MTCP
ET-6000,
ISaGRAF controllers (I-8417/8817/8437/8837, I-7188EG, I-7188XG, Wincon-8x37)

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000