How to use GSM/GPRS modems?

Applied to:

Platform	*OS version*	*XPAC utility version*
XPAC series	*All versions (WinCE6)*	*All versions*

Refer to the link below regarding of the solution of GSM/GPRS modems used on XPAC.
http://m2m.icpdas.com/gtm-201.html

And refer to the page36 of the user manual below for more details.
ftp://ftp.icpdas.com/pub/cd/usbcd/napdos/gprs_gsm_modem/gtm-201_modem/manual/gtm-201_user_manual.pdf

Note: Please contact us for the XPAC driver.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000