● How to Create NTP Server Under No External Network Environment?


In a factory or special circumstances, the network are usually private and could not connect with external network. It is necessary to set up an NTP server to provide internal equipment time calibration to make sure that all devices have the same time. This article explains:

1. How to set up an NTP Server environment?
2. How to set the time of UA products and NTP Server?
3. NTP stratum

〔This example operate under Windows 10 environment〕


1. How to set up an NTP Server Environment?


Set up Firewall.



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


Right click on [Inbound Rules] and then choose [New Rule]







LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


Choose [UDP], [Specific local ports]: 123





Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000






Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


Download and Install NTP Packages

Linkage: https://www.meinbergglobal.com/english/sw/ntp.htm

(ntp-4.2.8p15-win32-setup.exe)



After installation, Execute [Edit NTP Configuration]



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

After deleting all the contents in the file, copy and paste the following contents and save them.

```
# NTP Network Time Protocol
# **** ATTENTION ****: *You have to restart the NTP service when you change this file to activate the changes*
# PLEASE CHECK THIS FILE CAREFULLY AND MODIFY IT IF REQUIRED
# Configuration File created by Windows Binary Distribution Installer Rev.: 1.27    mbg
# please check http://www.ntp.org for additional documentation and background information
# restrict access to avoid abuse of NTP for traffic amplification attacks
# see http://news.meinberg.de/244 for details
restrict default noquery nopeer nomodify notrap
restrict -6 default noquery nopeer nomodify notrap

# allow status queries and everything else from localhost
restrict 127.0.0.1
restrict -6 ::1

# if you need to allow access from a remote host, you can add lines like this:
# restrict <IP OF REMOTE HOST>

# Use drift file
driftfile "C:\Program Files (x86)\NTP\etc\ntp.drift"


# your local system clock, could be used as a backup
# (this is only useful if you need to distribute time no matter how good or bad it is)
server 127.127.1.0 prefer
# but it should operate at a high stratum level to let the clients know and force them to
# use any other timesource they may have.
fudge 127.127.1.0 stratum 3

# Use specific NTP servers
#server tw.pool.ntp.org iburst minpoll 6 maxpoll 7
#server time.google.com iburst minpoll 6 maxpoll 7

# End of generated ntp.conf --- Please edit this to suite your needs
```



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

While have no permission to save this file, please save this txt file into another location.




Replace the previous ntp.conf file with new saved one.

File route: C:\Program Files (x86)\NTP\etc



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


Open Task Manager by press Ctrl+Alt+Del, and then choose [Services] tag, right click to NTP and select [Restart]




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2. How to set the time of UA products and NTP Server?

Login UA Web UI, click [System Setting] > choose [Time Setting], choose "Customize the Server" and key in IP and choose Time Zone, press [Save].





<NOTE>

If you press [Save] for the [Set the Time Manually], the [NTP time synchronization] function will turn off. If you need to restart the NTP Time, re-check [NTP time synchronization] settings and then click [Save].


LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3. NTP stratum

The range of NTP hierarchy that can synchronize is from 0 to 15, if it exceeds the range, it cannot be synchronized.

When installing the NTP Server file < ntp-4.2.8p15-win32-setup.exe >, the value we currently set in ntp.conf is 3.

If you need to adjust the stratum value, all devices must be within this range, and then refer to Chapter 1 in this document to restart the NTP settings in [Task Manager].



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000