How to enable/display Power management to control turn the display On/Off

Applies to:

Platform	*OS version*	*PAC utility version*
WinPAC series	*All versions (WinCE7)*	*All versions*
ViewPAC series	*All versions (WinCE7)*	*All versions*

Display off (On to System Idle status)


The display will be turned off automatically, while the system state is system idle.

Recovery Display (System Idle to on status)

If you do nothing on WinPAC after 6 minutes (1 user idle time + 5 system idle time, the display will turn off. You can move mouse or press the keyboard button to wake up the display (turn the display on)

Modified the system idle timeout

Step1: Click Start -->Control Panel-->Power-->Schemes->AC Power




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Step2: Select AC Power from Power Scheme

Step3: Modified the time value from "**Switch state to System Idle**"

Step4: Run WinPAC utility and click “Save and Reboot” to save the UI language.

Note: The default value for system Idle is 5 minutes




Disable the display on/off by PM

Step1: Click Start -->Control Panel-->Power-->Schemes

Step2: Select AC Power from Power Scheme

Step3: Set the time value to Never on "**Switch state to System Idle**" and "**Switch state to User Idle**"



Note: The time value 0 of System Idle is to disable this function

Note:

==========

The OS have 4 different power states (On /User Idle/System Idle/Suspend) that will be the four states of the internal power manager state machine. The transition from On to User Idle and User Idle to Suspend is done after timers expirations

==========

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000