Classification:
Product Functionality for I-7000/M-7000 series

Question

Can I use the 7000 module in the RS-232C network?

Answer

No, the 7000 use RS-485 network. So the user need a 7520, RS-232 to RS-485 converter, to convert the RS-232C signal to the RS-485 signal. That is to say that the user need at least two modules to form a minimum 7000 system. One is the 7520 and another is 7000 module (A/D or D/A or DI/O or Timer/Counter modules).

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000