Classification:
Product Functionality for I-7000/M-7000 series

Question

When to use repeater in the RS-485 network?

Answer

The user should use repeater when the network has more than 256 modules, or it has been over 1.2 Km distance.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000