Classification:
Software Development for I-7000/M-7000 series

Question

Can the baud rate be changed?

Answer

Yes, the validate baud rate are 1200, 2400, 4800, 9600, 19200, 38400, 57600 and 115200 BPS. PC can send out the command string under all these baud rate. Refer to Sec. 2.7 of the Getting Start file (http://www.icpdas.com/web/product/download/io_and_unit/rs-485/document/quick_start/7000/I-7000_Get_Start_en.pdf) for baud rate change.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000