
ALM-04-MRTU Installation Guide

V1.0, JAN 2020


This guide provides the procedures and instructions necessary to attach the ALM-04-MRTU on the panel.

1. Prepare a panel with a maximum thickness of 3 mm, and cut the hole to the specified size




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2. Attach the ALM-04-MRTU to the cut-out hole




3. Rotate the front cover counterclockwise until the screw hole appears




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

4. Wrap the **Gasket** around the **Screw (M4 x L8)**




5. Insert the screw into the screw hole



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

6. Make sure the panel clip is fitted and locked on the panel



Technical Support

ftp://ftp.icpdas.com.tw/pub/cd/alm_cd/alm_04_mrtu/manual/

service@icpdas.com

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000