How to automatically hide the taskbar


Applies to:

Platform	*OS version*	*WinPAC/ViewPAC utility version*
WP-8x3x/ WP-8x4x	*All versions*	*All versions*
WP-5000	*All versions*	*All versions*
VP-23W1/ VP-25W1	*All versions*	*All versions*
VP-4131	*All versions*	*All versions*

Depending on your preferences, you can set the taskbar to be automatically hidden when the mouse is not over. If to set the taskbar to be automatically hidden, perform the following steps:


Step 1: Set the taskbar to hidden.

1.1. Start the WinPAC/ViewPC Utility, and then click the “System Setting” tab.




LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1.2. Check the “Auto Hide” option.




Step 2: Save the settings.

2.1. Click the “**File**” → “**Save and Reboot**” menu option on the WinPAC/ViewPC Utility.




2.2. Click the “Yes” button and wait for the device to reboot.



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

After rebooting, the taskbar will be hidden automatically.



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Revision History

Revision	Date	Description
1.0.1	2013/08/06	NEW: Added support information for WP-5000 and VP-4131.
1.0.0	2010/02/12	Initial release

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000