
# How to change the desktop background image

***Applies to:***


| *Platform* | *OS version* | *WinPAC/ViewPAC utility version* |
|---|---|---|
| *WinPAC series* | *All versions* | *All versions* |
| *ViewPAC series* | *All versions* | *All versions* |

Use the follow steps to change the desktop background image of “WinCE5.0”:

Note: The desktop background image needs be a pixel-based bitmap image file (*.bmp) and it is displayed as below:




**Step 1:** Open the **Control panel** by clicking Start >> Settings >> Control Panel, and then double click the display icon for Display.








Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

**Step 2:** Click the Background tab and click **Browse** to choose your image file. After selecting the image file, clicking OK of the pop-up dialog, and then click OK on Display Properties window.

**Note:** The image file needs be a *.bmp file and be saved in System_disk folder.




**Step 3:** Launch WinPAC Utility and click **File** >> **Save** to save the setting.






Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

## Revision History

| Revision | Date | Description |
|---|---|---|
| 1.0.0 | 2013/05/16 | Initial release |
| | | |
| | | |



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000