How to change the display type for WP-8x4x

Applies to:

Platform	*OS version*	*WinPAC/ViewPAC utility version*
WP-8x3x	*N/A*	*N/A*
WP-8x4x	*All versions *1*	*All versions*
VP-25W1	*N/A*	*N/A*
VP-23W1	*N/A*	*N/A*

**1: VGA resolution 800 * 600 is applied for all version of WP-8x4x.*
*VGA resolution 640 * 480 is valid on OS V1.3.0.0 and later of WP-8x4x.*
N/A: Not applicable to this platform and OS.


The default display resolution for WP-8x4x is “800*600”. You can change the display resolution depending on your preferences by the following steps.

Tips & Warnings

If your monitor doesn’t support the display mode that you set, the monitor may not display correctly.

Step 1: Change the display resolution.

1.1. Start the WinPAC utility on the desktop, select the display resolution and then press “Setting” button.




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Step 2: Save and Reboot your WinPAC.

2.1. Start the WinPAC utility on the desktop and click "**File**"→"**Save and Reboot**".

2.2. Click the "**Yes**" button and wait for the device to reboot.



Tips & Warnings

If nothing displayed on your monitor while booting, the display settings selected on the WP-8x4x may be not be supported by your monitor.

*Please see the document "**W1-009-03**: How to change the display type for WP-8x4x when display out of range" for more details.*

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Revision History

Revision	Date	Description
1.0.0	2010/02/12	Initial release

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000