How to enter characters without a keyboard


Applies to:

Platform	*OS version*	*WinPAC/ViewPAC utility version*
WP-8x3x/ WP-8x4x	*All versions*	*All versions*
WP-5000	*All versions*	*All versions*
VP-23W1/ VP-25W1	*All versions*	*All versions*
VP-4131	*All versions*	*All versions*

The WinPAC/ViewPAC only has one USB port; if there is no USB hub available for a keyboard, Win CE provides an input panel to enter characters with a mouse or on touch panel.


To enter characters without a keyboard, perform the following steps:

Step 1: click on the icon that the arrow indicates in the diagram below.




LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

The input panel is shown as below:



Step 2: Click the key for the character you want to enter on the Input Panel.



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Revision History

Revision	Date	Description
1.0.1	2013/08/06	NEW: Added support information for WP-5000 and VP-4131.
1.0.0	2010/02/12	Initial release

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000