
How to hide the shortcut icons on desktop

Applies to:

Platform	*OS version*	*WinPAC/ViewPAC utility version*
WP-8x4x	*V1.6.1.1 and later*	*V2.0.2.7 and later*
WP-8x3x	*V1.3.0.1 and later*	
WP-5000	*V1.1.1.0 and later*	
VP-23Wx/ VP-25Wx	*V2.2.0.0 and later*	
VP-413x	*V2.4.1.0 and later*	


To hide the shortcut icons on desktop, please use the version 2.0.2.7 or later of WinPAC Utility and follow the steps below:

Step 1: Launch WinPAC Utility.
Step 2: Check the Blank Desktop checkbox on the “System Settings” tab.




LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Step3: Click “Save and Reboot” from the “File” menu.



After rebooting, the shortcut icons on desktop are hidden.



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Revision History

Revision	Date	Description
1.0.0	2013/05/16	Initial release

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000