How to set the startup programs on WinCE PAC

Applies to:


Platform	*OS version*	*WinPAC/ViewPAC utility version*
WP-8x3x/ XP-8x4x	*All versions*	*All versions*
WP-5000	*All versions*	*All versions*
VP-23W1/ VP-23W1	*All versions*	*All versions*
VP-4131	*All versions*	*All versions*

In WinPAC (and ViewPAC) utility, it offers an easy-to-use interface to manage the startup programs. The programs which are set in the utility will run automatically at system startup.

Here we illustrate the steps of how to set the startup programs and clear those settings.


Part 1. Set the startup programs

Setp1. Start the WinPAC/ViewPAC Utility on the desktop and then click the "Auto Execution" tab.




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


Step2. Click the “Browse” button and then select the program you want to run automatically after PAC boot-up.



Step3. Click the “OK” button.




Step4. Click the “Setting” button.




LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Step5. Click "**File**" and then click "**Save**" to save the setting.




Step6. Click the "**Yes**" button.




Step7. Reboot the PAC, the specified programs will run automatically.

Part 2. Clear the startup programs settings

Step1. Start the WinPAC/ViewPAC Utility click the "Auto Execution" tab.




Step2. Click the "**Browse**" button and leave the Name column empty.




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


Step3. Click the "**X**" button.



Step4. Click the "**File**" item and then click "**Save**" to save the settings.



Step5. Click the "**Yes**" button.



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Revision History

Revision	Date	Description
1.0.1	2013/08/06	NEW: Added support information for WP-5000 and VP-4131.
1.0.0	2010/02/12	Initial release

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000