How to set the taskbar always on top?


Applies to:

Platform	*OS version*	*WinPAC/ViewPAC utility version*
WP-8x3x/ WP-8x4x	*All versions*	*All versions*
WP-5000	*All versions*	*All versions*
VP-23W1/ VP-25W1	*All versions*	*All versions*
VP-4131	*All versions*	*All versions*

Depending on your preferences, you may want to set the taskbar to be always on top; it means that the taskbar is not shielded by other windows. To set the taskbar to be always on top, perform the following steps:


Step 1: Set the taskbar on top.

1.1. Start the WinPAC/ViewPAC Utility on the desktop, and then click the "**System Setting**" tab.




LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1.2. Check the "**Always On Top**" option.




Step 2: Save the setting.

2.1. Click the "**File**" → "**Save and Reboot**" menu option.




2.2. Click the "**Yes**" button and wait for the device to reboot.



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

After rebooting, the taskbar will not be covered by any other windows.



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Revision History

Revision	Date	Description
1.0.1	2013/08/06	NEW: Added support information for WP-5000 and VP-4131.
1.0.0	2010/02/12	Initial release

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000