How to use the I-8135W to expand the Ethernet port number

Applies to:

Platform	*OS version*	*WinPAC/ViewPAC utility version*
WinPAC series	*N/A*	*N/A*
ViewPAC series	*All versions*	*All versions*

N/A: *Not applicable to this platform and OS.*

Please perform the follow steps to expand the Ethernet port number with I-8135W.

Step1: Turn off the ViewPAC and then insert the I-8135W module to any slot.


Step2: Power on the ViewPAC, execute the ViewPAC_Utility,
click the “Ethernet settings” tag and select the "8135” tag.

Step3: Check the “Enable 8135 Module” checkbox; set using DHCP or static IP.
If using static IP, assign the valid IP address, Mask, Gateway and DND server.

Step4: Press the setting button.

Step5: Select “File“ -> “Save and Reboot“ from top toolbar, the setting will take effect after restart.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Revision History

Revision	Date	Description
1.0.0	2013/05/16	Initial release

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000