How to automatically hide the taskbar

Applies to:

Platform	***OS version***	***XPAC utility version***
XPAC series	*All versions (WinCE6)*	*All versions*

Depending on your preferences, you can set the taskbar to be automatically hidden when the mouse is not over. If to set the taskbar to be automatically hidden, perform the following steps:

Step 1: Set the taskbar to hidden.

1.1. Start the XPAC Utility on the desktop, and then select the “General” tab.



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


1.2. Check the “Auto Hide” option.



Step 2: Reboot your XPAC.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Step 3: After rebooting, the taskbar will be hidden automatically**.**



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000