How to calibrate a Penmount USB touch panel


Applies to:

Platform	*OS version*	*XPAC utility version*
XPAC series	*All versions (WinCE6)*	*All versions*

N/A: *Not applicable to this platform and OS.*

Use a touch panel and a keyboard at the same time on XP-8x4x.

The XP-8x4x series only has two USB ports, so if you want use a touch panel and keyboard/mouse at the same time. You will need a USB hub.




LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


To calibrate a PenMount USB touch panel, perform the following steps:

Step 1: Execute the calibration program.

1.1. After rebooting, click the Start->USB_TOUCH->PenMount-> Calibration.




1.2. Click the “4 Points” button. (Click the “9 Points” or “16 Points” button to obtain a more accurate calibration for the touch panel)



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1.3. Perform the calibration process.

1.3.1. Touch the "" icons on the monitor to perform the calibration process.



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000