# How to calibrate an Egalax USB touch panel


*Applies to:*

| *Platform* | *OS version* | *XPAC utility version* |
|---|---|---|
| *XPAC series* | *All versions (WinCE6)* | *All versions* |
| | | |
| | | |
| | | |

N/A: *Not applicable to this platform and OS.*

## Use a touch panel and a keyboard at the same time on XP-8x4x.

The XP-8x4x series only has two USB ports, so if you want use a touch panel and keyboard/mouse at the same time. You will need a USB hub.







LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


To calibrate an Egalax USB touch panel, perform the following steps:

**Step 1: Execute** the calibration program.

1.1. Click Start->Programs->USB_TOUCH->Egalax->eGalaxTouch.bat.





1.2. Click the “4 Pts Cal” button. (Click the “25 Pts Cal” button to obtain a more accurate calibration for the touch panel)







Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1.3. Perform the calibration process.
1.3.1. Touch the “X” icons on the monitor to perform the calibration process.








LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000