
How to find the system information

Applies to:

Platform	***OS version***	***XPAC utility version***
XPAC series	*All versions (WinCE6)*	*All versions*

To find the system information, perform the following steps:

Step 1: Start the XPAC Utility on the desktop, and then select the “Device Information” tab.



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000