How to use Autorun in plugging USB Disk


Applied to:

Platform	*OS version*	*XPAC utility version*
XPAC series	*All versions (WinCE6)*	*V1.0.2.9 or later*

You have to complete two parts, add file “AutorunCE.inf” in flash device, and enable this function at XPAC_Utility

Part 1: Add file “AutorunCE.inf” in flash device
Copy this block to your AutorunCE.inf

```
[autorun]
OPEN=xxx.exe
```



This simple AutorunCE.inf file specifies XXX.exe as the application to run when AutoRun is activated.

[autorun]
The autorun section contains the default AutoRun commands.

OPEN=XXX.exe
Specifies the path, file name to the application that AutoRun launches when a user plugging a flash device. It is the CreateProcess function that is called by AutoRun.

EX1: USB:\INotepad.exe


→ OPEN=INotepad.exe

EX2: USB:\NEW Folder\INotepad.exe

→ OPEN=NEW Folder\INotepad.exe

Part2: Enable this function at XPAC_Utility

Open XPAC_Utility, and then select tab “General”.Click checkbox “Enable Autorun in plugging USB Disk” and reboot.



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000