How to calibrate a ViewPAC touch panel


Applies to:

Platform	*OS version*	*WinPAC/ViewPAC utility version*
ViewPAC	*All versions*	*All versions*

N/A: Not applicable to this platform and OS.


The touch screen has function with the default calibration. It is necessary to calibrate your screen when it works not precise.

1) Run the 05 Point Calibration.exe on the desktop.




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3) Tap the touch pen in the exact center of each of the calibration markers (+)



4) Touch the panel to finish the calibration program
5) Run the View PAC Utility to save the settings and reboot the View PAC





LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000