How to calibrate an ELO serial touch panel


Applies to:

Platform	*OS Version*	*PAC Utility Version*
WinPAC	*All Versions*	*All Versions*


Tips & Warnings

Serial COM Ports 1 and 4 on WP-8000 are standard female/male RS-232 COM Ports.
*If COM3 is used to connect to the touch panel, you will need a "**NULL MODEM**".*


Standard Wiring



Connecting to COM1




Connecting to COM4



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Connecting to COM3




To calibrate an ELO serial touch panel, perform the following steps:

Step 1: Execute the calibration program.


1.1. Click the My Device →System_Disk→Drivers→Serial_TOUCH → ELO →LNK →Serial_EloVa.



1.2. Touch the "**+**" icons on the monitor one by one to perform the calibration process.




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000



Step 2: Reboot your WinPAC.

2.1. Start the PAC utility and click the "**File**" → "**Reboot**" menu option.

2.2. Click the "**Yes**" button and wait for reboot.



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000