
How to change the input Panel size

Applies to:

Platform	*OS Version*	*PAC Utility Version*
WinPAC	*All Versions*	*All Versions*
ViewPAC	*All Versions*	*All Versions*

To change the Input Panel size, perform the following steps:


Step 1: Choose the Control Panel. Now the Panel size is large.



Step 2: Choose the Input Panel.




Step 3: Click the "**Options**" button.




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Step 4: Select Small keys and then click the "**OK**" button.



Step 5: After performing steps 1 to 4, you will see the size of the input panel become small.



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000