How to set the startup programs on WinCE PAC

Applies to:


Platform	*OS Version*	*PAC Utility Version*
WinPAC	*All Versions*	*All Versions*
ViewPAC	*All Versions*	*All Versions*

In PAC utility, it offers an easy-to-use interface to manage the startup programs. The programs which are set in the utility will run automatically at system startup.


Here we illustrate the steps of how to set the startup programs and clear those settings.

Part 1. Set the startup programs

Setp1. Start the PAC Utility on the desktop and then select the "Auto Execution" tag.




Step2. Click the "Browse" button and then select the program you want to run automatically after PAC boot-up.




Step3. Click the **"OK"** button.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000




Step4. Click the **"Apply"** button to save setting.



Step5. Reboot the PAC, the specified programs will run automatically.


Click "**File**" → "**Reboot→Yes**"




Part 2. Clear the startup programs settings

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


Step1. Start the WinPAC/ViewPAC Utility click the “Auto Execution” tag.



Step2. Click the “**Clean**” button .



Step3. Click the **“Apply”** button to save setting.



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000