How to set the taskbar always on top?


Applies to:

Platform	*OS Version*	*PAC Utility Version*
WinPAC	*All Versions*	*All Versions*
ViewPAC	*All Versions*	*All Versions*


Depending on your preferences, you may want to set the taskbar to be always on top; it means that the taskbar is not shielded by other windows. To set the taskbar to be always on top, perform the following steps:

Step 1: Set the taskbar on top.

1.1. Click the "**Properties**".




1.2. Check the "**Always On Top**" option.



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

The taskbar will not be covered by any other windows**.**



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000