
How to use AutoRun in plugging USB Disk

Applies to:

Platform	*OS Version*	*PAC Utility Version*
WinPAC	*All Versions*	*All Versions*
ViewPAC	*All Versions*	*All Versions*

You have to complete two parts, add file “AutorunCE.inf” in flash device, and enable this function at PAC_Utility

Part 1: Add file “AutorunCE.inf” in flash device
Copy this block to your AutorunCE.inf





```
[autorun]
OPEN=xxx.exe
```

This simple AutorunCE.inf file specifies XXX.exe as the application to run when AutoRun is activated.

[autorun]
The autorun section contains the default AutoRun commands.

OPEN=XXX.exe
Specifies the path, file name to the application that AutoRun launches when a user plugging a flash device. It is the CreateProcess function that is called by AutoRun.

EX1: USB:\INotepad.exe
→ OPEN=INotepad.exe
EX2: USB:\NEW Folder\INotepad.exe
→ OPEN=NEW Folder\INotepad.exe



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Part2: Enable this function at PAC_Utility

Open PAC_Utility, and then select tab “General”.Click checkbox “Enable Autorun in plugging USB Disk” and reboot.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000