
How to use the Network ID (User name/Password/Domain) to access to network resources

Applies to:


Platform	OS version	PAC utility version
WinPAC series	All versions (WinCE7)	All versions
ViewPACseries	All versions (WinCE7)	All versions

Please perform the follow step to access to network resources.

Step 1: **Click** Start -->Control Panel-->Owner




Step 2: Select Network ID tab and input the user name, Password and Domain




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Step 3: Click the “File-> Reboot” menu option to reboot the WinPAC/ViewPAC



Step 4: Enter the address of the network resource at the Address bar, such as \\rd1-sean.
If the user name, Password and Domain is correct for this network resource, the network resource can logon. If not, a login dialog box will ask you to input the user name, Password and Domain shown as following.



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000