GW-7828 FAQ


Q1、The default Modbus ID of the GW-7828 is 1. How can I change it？ 2

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Q1、The default Modbus ID of the GW-7828 is 1. How can I change it？

A：

First, switch the GW-7828 to **configuration mode** (set **Init = OFF**, **Mode = ON**).
Then, connect to the device using the **Utility** software. In the upper-right corner of the window, you will see the **Node ID** setting field.
Enter the desired Modbus ID and click the **Set** button. When the confirmation dialog appears, click **“Yes (Y)”**, and the Modbus ID will be successfully updated.



(2025/12/24, Ming)

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000