How to Use PDS & I-7188E series product in Linux?

Applies to:		No. L6-007
Platform	OS version	SDK version
Linux	All versions	All versions

At first, user need to download PDS & I-7188E library as below link: **pds700_lib.tgz**

More detailed information, user can refer to **PDS700-Linux-Manual.pdf** document.

To installation and running library and demo, follow the procedure described below:

Step 1: Decompress pds700_lib.tar.gz file

#tar zxvf pds700_lib.tar.gz

Step 2: Compile pds700_lib file

#cd pds700_lib

#make

Step 3: Run Demo (You have to get IP first)

#cd examples

#./pds_info [ip] //Get Device information

User can use Windows application - "VxComm Utility" to get Device, for more information about VxComm utility please visit the link below http://www.icpdas.com/products/Software/VxComm/vxcomm.htm

Copyright © 2016 ICP DAS Co., Ltd. All Rights Reserved.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000