SMS-530 FAQ

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Tables of Content

Q01：I wrote in the hyperterminal +++hello and pressed enter 50 times, but my cellphone only receive 3 SMS. why it doesn't work and why sometimes it does work? 3
Q02：I cannot send out the message when we insert the phone number with “+“ in front of the phone number. 3
Q03：How to use SMS-530 to trigger SMS with ON and OFF at a same channel? 3

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Q01：I wrote in the hyperterminal +++hello and pressed enter 50 times, but my cellphone only receive 3 SMS. why it doesn't work and why sometimes it does work?

A01：When SMS-530 sends SMS, the command from COM3 will be ignored until it finish sending SMS. SMS-530 need about 3~5 seconds to send SMS. Add above 5 seconds delay time to every command, ensure that every message from COM3 will be sent.

Q02：I cannot send out the message when we insert the phone number with “+“ in front of the phone number.

A02：The SMS-530 cannot use "+" symbol to replace international call prefixes, so it only use general international call prefixes to send SMS.

Q03：How to use SMS-530 to trigger SMS with ON and OFF at a same channel?

A03：SMS-530 only use ON or OFF to trigger SMS

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000