Q: How to connect ICP DAS M-7000 I/O modules to WISE-580x?

A:

Please refer to WISE-580x Modbus RTU Master Application Example (step 5 to step 8) for detailed setting information. For channel settings, please refer to Modbus Mapping Table and user manual for detailed setting information.

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000