BNET-2310M Quick Start

v1.0, October 2024

Packing List

In addition to this guide, the package includes the following items :



BNET-2310M



Screw Driver (1C016)

Technical Support


service@icpdas.com

www.icpdas.com

Resources

How to search for drivers, manuals and spec information on ICP DAS website.

- For Mobile Web




- For Desktop Web



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

BNET-2310M Pin Assignment







Power Input & Special functionality	
Pin	Description
INIT	For restoring default account, password, or IP address. Please refer to the chapter 3 of the manual.
FW	For updating the firmware. Please refer to the chapter 4 of the manual.
N/A	Don't care.
P.PWR	DC Power 10V ~ 30V input
P.GND	DC Power GND



Digital and Analog IO pins	
Pin	Description
AI3	Analog Input 3 +
AI2	Analog Input 2 +
AI1	Analog Input 1 +
AI0	Analog Input 0 +
AGND	Analog Input GND
AO1	Analog Output 1 +
AO0	Analog Output 0 +
AGND	Analog Output GND
DI3	Digital Input 3
DI2	Digital Input 2
DI1	Digital Input 1
DI0	Digital Input 0
DO3	Digital Output 3
DO2	Digital Output 2
DO1	Digital Output 1
DO0	Digital Output 0
D.GND	Power GND for IO
D.PWR	DC 10V~30V for IO

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

BNET-2310M Wire Connection

Analog Type	Wire Connection
Analog Input	
Analog Output	

Digital Input	Wire Connection
ON State	
OFF State	

Digital Output	Wire Connection
ON State	
OFF State	

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

BNET-2310M LED Indication

LED	LED Status	BNET-2310M Status
All LED	Light up each one in turn	Firmware update mode.
	Blinks once in 500ms	Initial mode
PWR	ON	Power on.
	Blinks every 500ms	Hardware failure.
LAN	ON	The Ethernet cable is connected to the switch.
	OFF	The Ethernet cable is not connected to the switch.
BIP	ON	Receiving BACnet/IP messages or is communicating with client.
	Blinks every 500ms	Idle.
	OFF	The Ethernet cable is not connected to the switch.

BNET-2310M Web Connection

BNET-2310M Factory Default and Initial Mode			
Network Information	IP	192.168.255.1	Network parameters can be changed according to your application.
	Mask	255.255.0.0	
	Gateway	192.168.0.1	


BNET-2310M Login Information

The default login information is as follows.

Account: admin

Password: admin





Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000