CAN-2088C/D Quick Start

V3.0, Jan 2025

Packing List

In addition to this guide, the package includes the following items:



CAN-2088C/D



Screw Driver

Technical Support


service@icpdas.com

www.icpdas.com

Resources

How to search for drivers, manuals and spec information on ICP DAS website.

- For Mobile Web




- For Desktop Web



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

1 Node ID, baud rate and terminal resistance

According to the user's requirements for CANopen/DeviceNet network, set the node ID and CAN baud rate of this module on the CANopen/DeviceNet network. If the module is located at the terminal of the network, according to the standard CANopen/DeviceNet network specification, this module must enable the terminator resistance.



CAN-2088C













BaudRate Rotary Switch	BaudRate (k bps)
0	10
1	20
2	50
3	125
4	250
5	500
6	800
7	1000

CAN-2088D

BaudRate Rotary Switch	BaudRate (k bps)
0	125
1	250
2	500

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


2 I/O channel connection

Output Type	ON State LED ON Readback as 1	OFF State LED OFF Readback as 0
Drive Relay	Relay On	Relay Off
		
Resistance Load		
		
Input Type	**ON State LED ON Readback as 1**	**OFF State LED OFF Readback as 0**
Relay Contact	Relay On	Relay Off
		
TTL/CMOS Logic	Voltage > 10 V	Voltage < 4 V
		
NPN Output	Open Collector On	Open Collector Off
		
PNP Output	Open Collector On	Open Collector Off
		


Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3 CAN port connection


2-wire Connection



3-wire Connection



4-wire Connection



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000