(P)ET-2218H-16/S1 Quick Start

v1.0, February 2025

Packing List

In addition to this guide, the package includes the following items:

(P)ET-2218H-16/S1 = (P)ET-2218H-16 + CN-1826M



(P)ET-2218H-16 *1



CN-1826M *1



Screw Driver *1

Technical Support


service@icpdas.com

https://www.icpdas.com

Resources

How to search for drivers, manuals and spec information on ICP DAS website.

- For Mobile Web



- For Desktop Web



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

(P)ET-2218H-16/S1 Assembly Chart for (P)ET-2218H-16 and CN-1826M

1. Insert the daughter board - CN-1826M
2. Unscrew the screw to remove the cover, fasten the screws to secure the CN-1826M to (P)ET-2218H-16

1. Insert the CN-1826M



2. Unscrew the screw to remove the cover, fasten the screws to secure the CN-1826M to (P)ET-2218H-16

