VP-4238-CE7 Quick Start

v2.2, Apr. 2023

Packing List

Apart from this guide, this package includes following items:



VP-4238-CE7



Stylus Pen



Panel clip * 4



I/O Slot Lid*3



Screwdriver



M4 x 30L Screw * 4



microSD card and SD/microSD adapter


Resources

How to search for drivers, manuals and spec information from ICP DAS website.

- **For Desktop Browser**



- **For Mobile Web**



Technical Support

service@icpdas.com
www.icpdas.com

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


1 Setting up ViewPAC

1) Ensure that the rotary switch is set to the “0” position.

2) Connect the positive terminal (+) of the power supply to the terminal PWR and the negative terminal (-) of the power supply to the P.GND.

> The input range of power supply is +12 to +48 V_{DC}.

3) Connect the USB mouse or USB keyboard to the USB port.




4) Turn on the ViewPAC.


Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


2 Use PAC Utility to Manage the ViewPAC

1) Double-click the shortcut of “PAC Utility” on the desktop.



2) Configure IP address (DHCP), FTP Server, auto execution files…, etc.






3) Reboot the ViewPAC to save all changes.


Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

3 Change the Language

1) Select “Start”, choose “Settings”, click “Control Panel”, and then click Regional Settings.

2) Click “User Interface Language” tab, drop down to select the language, and click OK.





3) Run the PAC Utility, and then reboot the PAC to save all changes.





Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

4 Version Identification

The match version rules for Workbench and Runtime:

- **Workbench 11.0** with **Runtime Ver. 2.xx (factory default)**
- Workbench **1.08** with Runtime Ver. **1.xx**

Figure for Version confirmation


Workbench **11.0**	Runtime Ver. **2.xx**
	
Workbench **1.08**	Runtime Ver. **1.xx**
※There's no version number on the top-left window. 	


Note: Win-GRAF runtime must be matched with Win-GRAF Workbench V11 (or later)

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

5 Download the Latest Win-GRAF Workbench V11 Along with the Runtime

Key in "**win-graf**" into Search Box at ICP DAS home page. Find and download Win-GRAF Workbench V11 from the "Software download" Tab.





Download Win-GRAF Workbench:


File Name	Version	File Date	Download Link	Remark
Win-GRAF Workbench Software	11.0.03	2023-01-12	Installer	Full software

6 Restore Old Version Win-GRAF Runtime (1.xx)

Win-GRAF runtime (2.xx) does not fully support files compiled by Win-GRAF Workbench version 1.08. If you'd like to restore the old version runtime, please download and restore the runtime of PAC by yourself to **restore it back to the 1.xx version** of Win-GRAF runtime.

The method to restore is as follows:

1) Drop down to the end of this Tab and download old version runtime.




Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2) Copy **“Win-GRAF_Installer_Old.Zip”** file into pen drive or micro SD card, and unzip it.

3) Install the runtime


Open the file folder “Win-GRAF_Installer_Old” from pen drive or micro SD card. Capture as below:




According to different CPUs, different execution files have to be selected:


- **XP-8x28-CE6** PACs: please install “WinGRAF_Installer_Old_**x86**.exe”
- **WP-9xx8-CE7**, **WP-8x28-CE7**, **WP-5238-CE7**, **VP-x2x8-CE7** PACs: please install “WinGRAF_Installer_Old_**ARM**v4I.exe”

After the PAC is successfully updated, reboot the PAC.



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000






7 Ethernet Port (Workbench Port) Settings

Win-GRAF runtime (2.xx) or above version can set the Ethernet port.

Keep it as default **1100**. After setting, click “Set” button and reboot Win-GRAF Runtime to save the changes.



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000